

**MIYAKE VALVE GUIDE LIST**

STOCK NO.	OEM NO.	DISCRIPTION				
VGHI2-1060	11122-1060	HINO		IN.EX.	EH700	
VGHI2-1070	11122-1070	HINO		IN	EH-300	
VGHI2-1080	11122-1080	HINO		IN.	EL100	
VGHI2-1140	11122-1140	HINO		IN.EX.	W04/06D	
VGHI2-1180	11122-1180	HINO		IN.EX.	H07C	
VGHI6-1041	11126-1041	HINO		EX.	EH-300	
VGHO8-634-920	12208-634-920	HONDA		IN.	EF	
VGIS1-21-001	1-11721-001-0	ISUZU		IN.EX.	8MA,6RB	
VGIS1-21-008	1-11721-008-0	ISUZU		IN.EX.	6SA1	
VGIS5-21-001	5-11721-001-0	ISUZU		IN.EX.	4/6BA/C/D/E1	
VGIS5-21-015	5-11721-015-1	ISUZU		IN.EX.	4FB/C/E/G1	
VGIS8-06-762	8-94206-762-0	ISUZU		EX.	G200,4ZB	
VGIS8-06-763	8-94206-763-0	ISUZU		IN.	G200,4ZB	
VGIS8-96-598	8-94396-598-0	ISUZU		IN.EX.	4/6HE/HG1	
VGIS9-21-113	11721-1130	ISUZU		IN.EX.	C221	
VGIS9-21-160	9-11721-160-0	ISUZU		IN.EX.	DA120/220/640	
VGMD16441	MD016441	MITSU.		IN.	2G23	
VGMD16445	MD016445	MITSU.		EX.	2G21/23	
VGMD20551	MD020551	MITSU.		IN.	4G51/2/3	
VGMD20561	MD020561	MITSU.		EX.	4G51/2/3	
VGMD50523	MD050523	MITSU.		IN.	4D56	
VGMD50527	MD050527	MITSU.		EX.	4D56	
VGME31293	ME031293	MITSU.		IN.EX.	6D10/14	
VGME31886	ME031886	MITSU.		IN.	4D30/1,6D15	
VGME31888	ME031888	MITSU.		EX.	4D30/1,6D15	
VGME51120	ME051120	MITSU.		IN.	6D20/2	
VGME51122	ME051122	MITSU.		EX.	6D20/2	
VGMZ0636	0636-10-104B	MAZDA		IN.EX.	XB	
VGMZF801	F801-23-090	MAZDA		IN.EX.	F8	
VGMZSE01	SE01-10-104	MAZDA		IN.EX.	HA	
VGNS1-30001	13211-30001	NISSAN		IN.	J13	
VGNS1-97001	13211-97001	NISSAN		IN.	RD	PD
VGNS1-97003	13211-97003	NISSAN	13211-96009	EX.	13202-97001	
VGNS1-V1700	13211-V1700	NISSAN		IN.EX.	SD22/3/5	
VGNS1-Z5500	13211-Z5500	NISSAN		IN.EX.	FE6/T	
VGNS1-Z5507	13211-Z5507	NISSAN		IN.EX.	FE6-TA	
VGNS2-40F00	13212-40F00	NISSAN		IN.	KA24	
VGNS2-43G01	13212-43G01	NISSAN		IN.EX.	TD27	
VGNS2-53Y60	13212-53Y60	NISSAN		IN.	VG30	
VGNS2-95005	13212-95005	NISSAN		IN.EX.	NE6/T, IN. RF	
VGNS2-96002	13212-96002	NISSAN		EX	PD	
VGNS2-97001	13212-97001	NISSAN		IN.	RD	
VGNS2-H0112	13212-H0112/1	NISSAN		IN.	A14	
VGNS2-H2311	13212-H2311	NISSAN		IN	A14	
VGNS2-V1700	13212-V1700	NISSAN				
VGNS2-V5011	13212-V5011	NISSAN		IN.	VG30	
VGNS2-W0410	13212-W0410	NISSAN		IN.	Z18/20/24	
VGNS2-W0510	13212-W0510	NISSAN		IN.	Z20D	
VGNS3-30002	13213-30002	NISSAN		EX.	J13	
VGNS3-40F00	13213-40F00	NISSAN		EX.	KA24	
VGNS3-53Y60	13213-53Y60	NISSAN		EX.	VG30	
VGNS3-H0112	13213-H0112/1	NISSAN		EX.	A14	
VGNS3-H2311	13213-H2311	NISSAN		EX.	A14	
VGNS3-V5011	13213-V5011	NISSAN		EX.	VG20/30	
VGNS3-W0410	13213-W0410	NISSAN		EX.	Z18/20/24	

VGNS3-W0510	13212-W0510	NISSAN		IN.	Z20D	
VGSZ5-73030	11115-73030-001	SUZUKI		IN.	F5A OLD	
VGTY2-10040	11122-10040	TOYOTA		IN.EX.	2E,3E	
VGTY2-15020	11122-15020	TOYOTA		IN.	2A,3A	
VGTY2-16020	11122-16020	TOYOTA		IN.	4AG	
VGTY2-23010	11122-23010	TOYOTA		IN.EX.	12R, 4R	
VGTY2-24020	11122-24020	TOYOTA		IN.	3K,4K	
VGTY2-25021	11122-25021	TOYOTA		IN.	2T/3T	
VGTY2-31020	11122-31020	TOYOTA		IN.	12R	
VGTY2-35020	11122-35020	TOYOTA		IN.EX.	22R	
VGTY2-38021	11122-38021/20	TOYOTA		IN.EX.	20/21/22R	
VGTY2-46010	11122-46010	TOYOTA		IN.	2J, H	
VGTY2-54011	11122-54010/1	TOYOTA		IN.EX.	L,2L	
VGTY2-54020	11122-54020	TOYOTA		IN.EX.	3L	
VGTY2-56021	11122-56021	TOYOTA		IN.EX.	B,3B&DG,DL	
VGTY2-56030	11122-56030	TOYOTA		IN.EX.	B,3B	
VGTY2-61011	11122-61011/0	TOYOTA		IN.	F	
VGTY2-64010	11122-64010	TOYOTA		IN.	1C	
VGTY2-67020	11122-67020	TOYOTA		IN.EX.	1KZ	
VGTY2-71020	11122-71020	TOYOTA		IN.	Y,2Y,3Y	
VGTY2-76020	11122-76020	TOYOTA		IN.EX.	2D	
VGTY6-15020	11126-15020	TOYOTA		EX.	2A,3A	
VGTY6-24020	11126-24020	TOYOTA		EX.	3K,4K	
VGTY6-46010	11126-46010	TOYOTA		EX.	2J,H,1Z	
VGTY6-61011	11126-61011/10	TOYOTA		EX.	F	
VGTY6-64010	11126-64010	TOYOTA		EX.	1C	